


Steelcase Series™ 1 and Series™ 2 Headrest or Coat Hanger Assembly Directions

For Steelcase Series 1 Chair and Stool



For Steelcase Series 2 Chair and Stool





If you have a problem, question, or request, call
your local dealer, or Steelcase Line 1 at
888.STEELCASE (888.783.3522)
for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico,
and the U.S. Virgin Islands, call: 1.616.247.2500)
Or visit our website: www.steelcase.com


© 2017 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.







Existing Screws
for Series 1






Existing Screws
for Series 2




Remove the existing screws.
These screws are not long
enough to hold headrest or
coat hanger.



Ensure parts have no new
gaps after assembly.



New Screws
for Series 1



New Screws
for Series 2

Hand-tighten only

