



If you have a problem, question, or request, call
your local dealer, or Steelcase Line 1 at
888.STEELCASE (888.783.3522)
for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico,
and the U.S. Virgin Islands, call: 1.616.247.2500)
Or visit our website: www.steelcase.com

© 2013 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.

1. Rotate seat depth knob clock-wise to extend seat forward.

2. Slip fingers between cushion flap and outer back shell on one side of the back cushion. Pull outward to disengage 'T' clips. Work from one side to the other. Fold flap over cushion face when completed.

3. Slip fingers between cushion and outer back shell in the center of the back on both sides. Lift cushion up and forward to unhook from top of back.

4. Lay cushion down. Detach two (2) rubber bungees from hooks.

5. Reverse procedure to install replacement back cushion.

NOTE: When bringing the wrap back over the top of the chair, push it towards the back, parallel to the seat so the alignment cones and hooks on the bottom and side *snap* together. If needed, adjust fabric at top to smooth.

