

1.0




Intertek This product is ETL listed and suitable only for indoor dry locations and approved for use at any height above the finished floor.

Adjust The Fixture Height




Back out (do not remove) the set screw on tip of the connector with the provided Allen wrench.




2 Back out (do not remove) the set screw on the conical connector with the provided Allen wrench.


3 Pull the coaxial cable out.




- 4 Cut the coaxial cable to the desired length.
- Gently twist the end of the coaxial cable between thumb and forefinger.




6 Tap the conical connector on a hard surface with the set screw facing down, so the plate inside drops into place.



Feed and push the coaxial cable into the conical connector. The coaxial cable will come to a stop point after being inserted 3/4" into the conical connector.




8 Keep pushing the coaxial cable into the connector while rotating the connector to ease feeding the inner wire into the tip of the connector. The outer wrapped wire will start wrinkling while being inserted another 1/2" into the connector.




Dook into the sight hole on the top of the connector to make sure that the inner wire is contacting the end of the connector.

 Hold the coaxial cable in place and tighten the set screw on tip of the connector with the provided Allen wrench.
<u>Make sure this set screw connection is tight.</u>



1 Firmly tighten the set screw on the conical connector.



Pull the coaxial cable toward the fixture to smooth the wrinkles.

SAVE THESE INSTRUCTIONS!

VISUAL COMFORT & CO.

7400 Linder Ave, Skokie, IL 160077 800.969.3347

www.visualcomfort.com

©2023 Visual Comfort & Co.. All rights reserved. The Visual Comfort & Co. logo is a registered trademark of Visual Comfort & Co. Visual Comfort & Co. reserves the right to change specifications for product improvements without notification