






- 1.** To remove arm cap, remove four (4) screws (1a) and remove cap from arm (1b). To replace arm cap, reverse steps 1a and 1b and tighten screws to 6-10 in-lbs.



Torx T-20



If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you.

(Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: www.steelcase.com

© 2019 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.