


**1.** Push trigger in (1a) and extend arm to the upmost position (1b), release trigger and press down until you hear a click (1c).

**2.** Insert T-pin (included) into hole on the front of the arm stalk (2a). While applying light downward pressure on the arm press the T-pin into the stalk. While maintaining pressure on T-pin, remove downward pressure on arm, push/hold trigger (2b) and pull up on the arm assembly (2c) to remove from chair.



**NOTE:** Make sure to install the arms on the correct side of the chair.

**3.** Peel thin plastic off the bottom of the arm stalk. Then go directly to step 4.

**4.** To install new arm assembly, simultaneously push trigger (4a) and align the lead screw and lead nut (4b), then insert new arm assembly into arm pocket (4c).

Repeat step 3 and 4 for opposite side.

