



# UTTERMOST


## ASSEMBLY INSTRUCTIONS

ITEM: 23664


PARTS LIST							
NO	DRAWING	PARTS NAME	Q'TY	NO	PARTS NAME	DRAWING	Q'TY
A		FLAT WASHER 5/16" * 3/4"	8PCS	1	SEAT FRAME		1PC
B		LOCK WASHER 5/16"	8PCS	2	RIGHT FRONT LEG		1PC
C		BOLTS DIA 5/16" * 2"	4PCS	3	LEFT FRONT LEG		1PC
				4	RIGHT BACK LEG		1PC
D		BOLTS DIA 5/16" * 2-1/4"	4PCS	5	LEFT BACK LEG		1PC
				6	LEFT SIDE STRETCHER		1PC
E		ALLEN WRENCH 5/16"	1PC	7	RIGHT SIDE STRETCHER		1PC
F		WOOD SCREW 1-3/4"	8PCS	8	FRONT STRETCHER		1PC
				9	BACK STRETCHER		1PC

ASSEMBLY BOLTS MAY NEED TIGHTEND AFTER USE


### STEP 1



### STEP 2



### STEP 3



**re-tighten the leg bolts after using a period of time**

To avoid wobbly product and gaps between legs and stretchers, please follow below steps to assemble:

- 1) Attach the legs. Do not completely tighten the bolts that hold the legs.
- 2) Attached the stretchers. Completely tighten the screws that hold the stretchers.
- 3) Set the chair on the floor to level and then finish tightening the leg bolts.