

## **ASSEMBLY INSTRUCTIONS**

**ITEM NO:**233068-004

**Description:** GRAZIA PENDANT – MATTE BLACK PLASTER

These instructions are provided for your safety. It is very important that they are read carefully and Completely before beginning installation of this chandelier. **We strongly suggest that all hard wired fixtures be installed by a professional electrician.**



### ***Parts Included:***

1. Main Body
2. Mounting spider
3. Canopy
4. Metal Ring/Hook Pipe (2pcs-18", 2pcs-12" & 2 pc-6")

### ***Hardware Enclosed:***

1. (2) Mounting Screws
2. (2) Plastic Wire Connectors
3. (1) Green ground screw

### ***To Install You Will Need:***

1. 2 people recommended
2. Phillips Screwdriver (Not Provided)
3. Electrical tape (Not Provided)
4. Wire cutters (Not Provided)

### ***To Assemble:***

1. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
2. Included are (2) 6" pipe, (2) 12" pipe and (2) 18" pipes. Determine which of these you will need to reach your desired length. At least (1) 6" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the ring part of the pipes toward the ceiling & hook part downwards.
3. Pass the wire through canopy
4. Shut off the main electrical supply from the main fuse box/circuit breaker.
5. Gently pull wiring down from ceiling junction box and allow to hang.
6. Remove mounting spider from the canopy by unscrewing the collar. Let the Canopy fall down.
7. Then you will find Mounting Spider/ Centre nipple in correct position.
8. Align holes in mounting spider with holes in junction box and attach with two mounting screws. Secure screws with a Phillips screwdriver.
9. Pull down the house/ junction box wire through the centre nipple for connection.
10. Insert the two stripped wires and the bare copper ground wire through the nipple assembly, locknut and mounting spider. Using the wire nuts, attach the ribbed wire to the white "neutral" house wire and the un-ribbed wire to the black "hot" house wire. Secure the wire nuts with black electrical tape. Connect the bare copper ground wire to the green house wire. It is imperative that the outlet box in your home be properly grounded  
**DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
11. Then push the canopy to the mounting spider & attach the 4 screw back to complete the electrical assembly.
12. Insert 1 Type A 60W bulbs (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
13. Restore power to junction box and test fixture.

### **CARE INSTRUCTIONS**

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.