

ASSEMBLY INSTRUCTION



WELLBORN SOFA-97"

Components



A
X1

Hardware

NO.	PICTURE	DESCRIPTION	SPEC.	QTY.
a		Plastic Washer	Ø8	5
b		Plastic Leg	Ø6	5

Assembly steps

