

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DMI17 NAME: Gaia Chandelier-UL

MATERIAL TYPE: Iron FINISH: Antique Brass

SOCKET TYPE:E12 TYPE B SOCKET QTY: 06

BULB WATTAGE: 40W BULB / 10W SBCFL / 9 W SBLED

VOLTAGE: 250 V ITEM NET WEIGHT:32.18 Lbs

PARTS INCLUDED:

Mounting Plate	Qty:	1
Canopy	Qty:	1
Pipes (1) 10"	Qty:	1
Small Bowl	Qty:	1
Medium Bowl	Qty:	1
Large Bowl	Qty:	1
Metal Finial	Qty:	1

HARDWARE INCLUDED:

Mounting Screws	2	Canopy Screw	4 Pcs
Plastic Wire Connector	2	Hexanguler Screw	1 Pc
Green Ground Screw	1	Allen Wrench	1 Pc

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
3. Gently pull wiring down from ceiling junction box and allow it to hang.
4. Remove mounting plate from the canopy by unscrewing the collar.
5. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:
Neutral fixture wire: White
Hot fixture wire: Black
Ground wire: Green
6. Carefully strip the outer insulation cover taking care that the insulation of the inner conductors is not damaged. Strip approximately 3" of the outer insulation cover to expose the three conductor wires. Strip 3/4" of the insulation off the three conductor wire.
7. Attach the Ground wire from the pendant to the Ground junction box wire (usually green or bare wire). Fasten each together with a wire nut and wrap the connection with electrical tape.
8. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
9. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
10. Gently tuck the wire connections neatly into the ceiling junction box.
11. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
12. Push canopy up over the mounting plate until it is flush with the ceiling.
13. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
14. Insert (6) **TYPE B 40W BULB / 10W SBCFL / 9 W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
15. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIO RS