

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DMI18	NAME: Hardy Chandelier
MATERIAL TYPE: Iron	FINISH: Antique Brass
SOCKET TYPE: E12 Type B	SOCKET QTY: 09
BULB WATTAGE: 25W/7W SBCFL/5 W SBLED	
VOLTAGE: 125 V	ITEM NET WEIGHT: 47.4LBS

PARTS INCLUDED:

Mounting Plate	Qty:	1
Canopy	Qty:	1

HARDWARE INCLUDED:

Mounting Screws	2
Plastic Wire Connector	2
Green Ground Screw	1

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
3. Gently pull wiring down from ceiling junction box and allow it to hang.
4. Remove the mounting plate from the canopy by loosening the canopy screws with a screwdriver.
5. Determine the chain length desired and if necessary, remove extra links from the chain and reconnect the chain to the nipple (hook) assembly. The electric supply wire that is woven through the chain should be cut off 12 inches longer than the chain.
6. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:
 - Neutral fixture wire: White
 - Hot fixture wire: Black
 - Ground wire: Green
7. Carefully strip the outer insulation cover taking care that the insulation of the inner conductors is not damaged. Strip approximately 3" of the outer insulation cover to expose the three conductor wires. Strip ¼" of the insulation off the three conductor wire.
8. Attach the Ground wire from the pendant to the Ground junction box wire (usually green or bare wire). Fasten each together with a wire nut and wrap the connection with electrical tape.
9. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
10. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
11. Gently tuck the wire connections neatly into the ceiling junction box.
12. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
13. Push canopy up over the mounting plate until it is flush with the ceiling.
14. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
15. Align the holes in Glass/Metal strips with main frame and tighten the same with metal bolts . Repeat the same procedure for other Glass/Metal Strips fitment too.
16. Insert (9) **TYPE B 25W BULB / 7W SBCFL / 5 W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
17. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIO RS