

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DWI31 NAME: Ardena Wall Sconce

MATERIAL TYPE: Resin FINISH: Faux Horn

SOCKET TYPE: E12 Type B SOCKET QTY: 2

BULB WATTAGE: B 25W BULB / 7W SBCFL / 5W SBLED

VOLTAGE: 125V ITEM NET WEIGHT: 5.1LBS



PARTS INCLUDED:

Mounting Plate Qty: 1

Back Plate Qty: 1

HARDWARE INCLUDED:

Mounting Screws Qty: 02

Plastic Wire Connector Qty: 02

Canopy Screw Qty: 01

TOOLS NEEDED (Not Included):

1 Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



*This Sconce can be mounted vertically only.

TO ASSEMBLE:

1. Shut off the main electrical supply from the main fuse box/circuit breaker.

2. Attach mounting plate to wall or junction box using mounting screws (C).

3. Connect ground wire from wall to ground wire from lamp using wire caps (A).

4. Attach house wire to lamp wires as shown. Fasten the pairs together with a wire caps. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**

6. Place Main Frame on the groove given on the top of Mounting Plate and fix by tightening the canopy screw (B) in the

predrilled hole at the bottom.

6. Insert **(2) TYPE B 25W BULB / 7W SBCFL / 5W SBLED** (not included) into each socket. **DO NOT EXCEED SPECIFIED WATTAGE.**

7. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and

For customer service questions call 1-800-338-2150

ARTERIO RS