

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: GDDMI01 NAME: Chene Chandelier

MATERIAL TYPE: Iron FINISH: Antique Brass

SOCKET TYPE: E26 Type A SOCKET QTY: 1

BULB WATTAGE: 100 W BULB/26W SBLED/20 W SBLED

VOLTAGE: 250V ITEM NET WEIGHT: 16.5LBS

PARTS INCLUDED:

Mounting Strip	Qty: 1
Canopy	Qty: 1
Canopy Screw	Qty: 4
Glass with Socket Clustre	Qty: 1
Air craft wire with bolt	Qty: 3
Screw Cap	Qty: 4+1 Extra

HARDWARE INCLUDED:

Mounting Screws	2
Plastic Wire Connector	2
Green Ground Screw	1

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
3. Gently pull wiring down from ceiling junction box and allow to hang.
4. There are three metal rods on top of the metal bowl, each with a threaded stud. The glass piece has three holes with metal fittings attached. Place the glass on top of the metal bowl, align the holes over the threaded studs, and then tighten the nuts on the ends of the air craft wire to secure the glass to the metal bowl.
5. Remove mounting spider from the canopy by unscrewing the side screws.
6. Inside the canopy, there is a second spider equipped with three metal height adjusters (air craft wire system). Chandelier height is adjusted through these air craft wire adjusters:
 - Slightly loosen the adjuster from the bottom.
 - Press the adjuster and pull/push the air craft wire to the required height and tighten the adjuster again.
 - Leave approximately 12 inches of extra wire and trim off the excess.
7. Place the mounting spider over the center of the ceiling junction box.
8. Align the holes in the mounting spider with the holes in the junction box and attach using two mounting screws. Tighten all screws with a Phillips head screwdriver.
9. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:
 - Neutral fixture wire: White
 - Hot fixture wire: Black
 - Ground wire: Green
10. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
11. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
12. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
13. Gently tuck the wire connections neatly into the ceiling junction box.
14. Push the canopy up over the mounting plate until it is flush with the ceiling. Align the holes in the mounting plate with the holes in the canopy and secure using the four canopy screws. Tighten the screws with a Phillips head screwdriver. After tightening, install the decorative screw caps by hand over each screw.
15. Insert **(1) TYPE A 100 W BULB / 26W SBLED / 20 W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
16. Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

A R T E R I O R S