

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: GDDL001 NAME: Will O Wisp Chandelier

MATERIAL TYPE: Iron FINISH: Bronze

SOCKET TYPE: E12 Type B SOCKET QTY: 3

BULB WATTAGE: 25W BULB / 7W SBCFL / 5W SBLED

VOLTAGE: 125V ITEM NET WEIGHT: 42.1LBS

PARTS INCLUDED:

Mounting Strip Qty: 1

Canopy Qty: 1

Canopy Screw Qty: 4+1 Extra

Glass Shade - 12" Qty: 1

Glass Shade - 9" Qty: 1

Glass Shade - 6" Qty: 1

Glass Cap Screw Qty: 9+1 Extra

Screw Cap Qty: 13+2 Extra

HARDWARE INCLUDED:

Mounting Screws 2

Plastic Wire Connector 2

Green Ground Screw 1

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
3. Gently pull wiring down from ceiling junction box and allow to hang.
4. Remove mounting spider from the canopy by unscrewing the side screws.
5. Place the mounting spider over the center of the ceiling junction box. 6. Align the holes in the mounting spider with the holes in the junction box and attach using four mounting screws.
7. Carefully inspect the pendant's fixture wire. It is a round supply cord with insulating cover. Inside the insulation cover there are three conductor wire as follows:

Neutral fixture wire: White

Hot fixture wire: Black

Ground wire: Green

8. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
9. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
10. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
11. Gently tuck the wire connections neatly into the ceiling junction box.
12. Push the canopy up over the mounting plate until it is flush with the ceiling. Align the holes in the mounting plate with the holes in the canopy and secure using the four canopy screws. Tighten the screws with a Phillips head screwdriver. After tightening, install the decorative screw caps by hand over each screw.
13. Insert **(3) TYPE B 25W BULB / 7W SBCFL / 5W SBLED** (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
14. There are three different sizes of glass shades, and each shade is marked with its size. The metal caps/sockets are also size marked. Match the correct glass shade with the corresponding cap. Carefully insert the glass shade into the metal cup and tighten the side screws one by one. **Do not overtighten the screws, as excessive pressure may damage the glass.** After tightening, install the decorative screw caps by hand over

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.