# ASSEMBLY INSTRUCTIONS

## ITEM DESCRIPTION:

ITEM NO.: DPI20 NAME: Caligo Pendant

MATERIAL TYPE: Glass / Iron FINISH: Ombre Silver

SOCKET TYPE: E12 Type B SOCKET QTY: 3

BULB WATTAGE: 25W / 7W CFL / 5W LED

VOLTAGE: 110V-120V ITEM NET WEIGHT: 16



## PARTS INCLUDED:

| | | |
|---|---|---|
| Mounting Plate | Qty: 1 | 1 |
| Canopy | Qty: 1 | 1 |
| Pipes (one 3", one 6", two 1: | Qty: 4 | 4 |
| Glass Shade | Qty: 1 | 1 |
| Finial (with threaded stud) | Qty: 1 | 1 |
| Metal Washer | Qty: 2 | 2 |
| Silicone Washer | Qty: 2 | 2 |

## HARDWARE INCLUDED:

| | | | |
|---|---|---|---|
| Mounting Screws | 2 | Allen Wrench | 1 |
| Plastic Wire Connector | 2 | | |
| Green Ground Screw | 1 | | |

**TO INSTALL YOU WILL NEED:**

These instructions are provided for your safety. Read them carefully and completely before beginning installation.

We strongly recommend that all hard-wired fixtures be installed by a licensed electrician.

**TO ASSEMBLE:**

1. Shut off power at the main fuse box or circuit breaker.
2. Carefully unpack all parts and hardware and lay them on a soft surface.
3. Choose the pipes you need for your desired hanging height. Included are one 3", one 6" and two 12" pipes; the 3" pipe must always be used.
4. Thread the fixture cord through the pipes with the threaded ends toward the ceiling. Screw the pipes together, starting at the fixture body and working up to the canopy, then tighten the set screw on each pipe with the Allen wrench (included).
5. Gently pull the wires down from the junction box and let them hang.
6. Remove the mounting plate from the canopy by unscrewing the collar.
7. Strip about 3" of the cord's outer jacket without nicking the inner wires, then strip 3/4" of insulation from each wire (white = neutral, black = hot, green = ground).
8. Connect the fixture ground wire (green or bare) to the junction box ground wire (usually green or bare) with a wire connector and wrap with electrical tape. If there is no ground wire in the box, attach the fixture ground wire to the green ground screw on the mounting plate.
9. Connect the white (neutral) fixture wire to the white junction box wire with a wire connector and wrap with electrical tape.
10. Connect the black (hot) fixture wire to the black junction box wire with a wire connector and wrap with electrical tape. Make sure no wire strands are exposed.

**DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**

11. Gently tuck all connections into the junction box.
12. Align the mounting plate with the junction box and attach it with the two mounting screws, using a Phillips screwdriver.
13. Slide the canopy up over the mounting plate until it is flush with the ceiling. Push the collar through the canopy, thread it onto the nipple of the mounting plate and turn it clockwise until the canopy is secure.
14. Insert three Type B bulbs, max 25W (or 7W CFL / 5W LED), not included, into the sockets. Do not exceed the maximum wattage.

**GLASS SHADE ASSEMBLY:**

15. Place a metal washer and then a silicone washer onto the threaded stud of the finial.
16. From outside the shade, push the finial stud through the hole at the bottom of the glass shade. Inside the shade, add the second silicone washer and then the second metal washer.
17. Screw the finial stud into the center pipe of the fixture body and tighten until the glass shade is secure.
18. Restore power at the breaker and test the fixture.

**IMPORTANT:**

The glass is fragile. Handle it carefully and do not over-tighten, which can crack or break the glass.

**CARE INSTRUCTIONS:**

Wipe with a soft, dry cloth. To protect the finish, avoid chemicals and household cleaners.