
ASSEMBLY INSTRUCTIONS

ARTERIORS

ITEM DESCRIPTION:

ITEM NO.: DPC47	**NAME:** Royalton Pendant
MATERIAL TYPE: IRON, GLASS	**FINISH:** BROWN NICKEL, SMOKE
SOCKET TYPE: E26	**SOCKET QTY:** 1
BULB WATTAGE: 60W /13W CFL/8W LED	**VOLTAGE:** 110V-120V
ITEM NET WEIGHT: 19.66 LBS	





PARTS INCLUDED:

Mounting Plate (A)	1	Hex Screw (E)	9
Canopy (B)	1	Lamp Assembly (F)	1
Collar Loop (C)	1	Glass Tube (G)	52
Rod (D)	4	Socket (H)	1

HARDWARE INCLUDED:

Mounting Screw (J)	2	Canopy Screw	
Plastic Wire Connector (K)	3	Allen Wrench (L)	1
Green Ground Screw	1		

TO INSTALL YOU WILL NEED:

• 2 people recommended • Phillips screwdriver • Allen wrench (included)

TO ASSEMBLE:

1. Shut off power at the main fuse box or circuit breaker.
2. Carefully unpack all parts and hardware and lay them on a soft surface.
3. Gently pull the wires down from the junction box and let them hang.
4. Remove the mounting plate (A) from the canopy (B) by unscrewing the collar loop (C).
5. Connect the lamp assembly (F) to the canopy (B) with rods D1-D4. Loosen the small hex screws (E) first, then tighten them with the Allen wrench (L) once all rods are connected. Check that all hex screws are tight.
6. Connect the fixture ground wire (bare) to the junction box ground wire (usually green or bare) with a wire connector (K) and wrap with electrical tape. If there is no ground wire in the box, attach the fixture ground wire to the green ground screw on the mounting plate (A).
7. Connect the white (neutral) fixture wire to the white junction box wire with a wire connector (K) and wrap with electrical tape.
8. Connect the black (hot) fixture wire to the black junction box wire with a wire connector (K) and wrap with electrical tape. Make sure no wire strands are exposed.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

9. Gently tuck all connections into the junction box.
10. Place the mounting plate (A) over the junction box, align the holes and attach it with the two mounting screws (J), using a Phillips screwdriver.
11. Slide the canopy (B) up over the mounting plate (A) until it is flush with the ceiling. Push the collar loop (C) through the canopy, thread it onto the nipple of the mounting plate and turn clockwise until the canopy is secure.
12. Insert one Type A bulb, max 60W (or 13W CFL / 8W LED), not included, into the socket (H). Do not exceed the maximum wattage.
13. Carefully hang the glass tubes (G) on the lamp assembly (F). Handle them gently to avoid scratches.
14. Restore power at the breaker and test the fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect the finish, avoid chemicals and household cleaners.

These instructions are provided for your safety. Read them carefully and completely before beginning installation. We strongly recommend that all hard-wired fixtures be installed by a licensed electrician.

Customer service: 1-800-338-2150