


## ROMEO SOFT T1

Designed by Philippe Starck, 1998


F6107007



## ROMEO SOFT T1

F6107007

EN



- 01. RF03203 – Romeo soft T1 cover ring
- 02. RF6100100 – Kit of silicone seats for cover ring
- 03. RF05286 – Fabric lamp shade
- 04. RF03201 – Acid-etched diffuser
- 05. RF6110200 – Contact rod small parts kit
- 06. RF05369 – S1/T1 bracket ring
- 07. RF04169 – E27 lamp holder
- 08. RF32262 – Led dimmer 1004P LFP100-240V 4-150WHL 4-25W
- 09. RF02813 – T1 grey support bracket
- 11. RF6138100 – Kit of transparent pads for base

ROMEO SOFT T1 F6107007

EN

## RF03203

ROMEO T1 COVER RING



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF03203**

ROMEO T1 COVER RING




Fig.1

Position the fabric lamp shade (N) on the support ring (D) ensuring to insert the hook threaded screws (R) into the apposite holes present in the support ring (D), fasten the small bolts (Q).

Collocate the silicone seats in there apposite holes underneath the cover ring (O).  
Rest the covering ring (O) on the pins (G).


WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF6100100

KIT OF SILICONE SEATS FOR COVER RING



Romeo  
Soft F  
p.05



Romeo  
Soft T1  
p.05

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF6100100**

KIT OF SILICONE SEATS FOR COVER RING




Fig.1

Position the fabric lamp shade (N) on the support ring (D) ensuring to insert the hook threaded screws (R) into the apposite holes present in the support ring (D), fasten the small bolts (Q).  
Collocate the silicone seats in there apposite holes underneath the cover ring (O).  
Rest the covering ring (O) on the pins (G).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF05286

FABRIC LAMP SHADE



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)

Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF05286**

FABRIC LAMP SHADE




Fig.1

Place the glass shade (P) on the support ring (D).  
Rest the covering ring (M) on the internal glass diffuser (L).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF03201

ACID-ETCHED DIFFUSER



Romeo  
Soft T1  
p.09



Romeo  
Moon T1  
p.07

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF03201**

ACID-ETCHED DIFFUSER




Fig.1

Remove the lamp bulb (l) if still present on the lamp device.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF03201**

ACID-ETCHED DIFFUSER




Fig.2

Insert the diffuser (H).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF03201**

ACID-ETCHED DIFFUSER




Fig.3

Insert the lamp-bulb (I).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF03201**

ACID-ETCHED DIFFUSER




Fig.4

Place the glass shade (P) on the support ring (D).  
Rest the covering ring (M) on the internal glass diffuser (L).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF6100200

KIT OF SCREWS/BOLTS FOR ROMEO



Romeo  
Moon F  
p.12



Romeo  
Moon T1  
p.12



Romeo  
Soft F  
p.12



Romeo  
Soft T1  
p.14

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF6100200**

KIT OF SCREWS/BOLTS FOR ROMEO




Fig.1

Rest the support ring (D) on the support brackets (E) and lock it by fastening it with the screws (F).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF6100200**

KIT OF SCREWS/BOLTS FOR ROMEO




Fig.2

Position the fabric lamp shade (N) on the support ring (D) ensuring to insert the hook threaded screws (R) into the apposite holes present in the support rind (D), fasten the small bolts (Q).  
Rest the covering ring (O) on the pins (G).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.


©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

## RF05369

SUPPORT RING



Romeo  
Moon T1  
p.16



Romeo  
Soft T1  
p.17

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF05369**

SUPPORT RING




Fig.1

Rest the support ring (D) on the support brackets (E) and lock it by fastening it with the screw/pivots (F).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF05369**

SUPPORT RING




Fig.2

Insert the diffuser (H).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

ROMEO SOFT T1 F6107007

EN

**RF05369**

SUPPORT RING




Fig.3

Insert the lamp-bulb (I).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF05369**

SUPPORT RING




Fig.4

Place the glass shade (P) on the support ring (D).  
Rest the covering ring (M) on the internal glass diffuser (L).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF04169

E27 LAMP HOLDER



Romeo  
Moon F  
p.21



Romeo  
Moon T1  
p.21



Romeo  
Soft F  
p.17



Romeo  
Soft T1  
p.22

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER




Fig.1




Fig.2

Remove the cover ring (O).  
Remove the fabric lamp shade (N) by unfastening the small bolts (Q).  
Unhook the fabric shade from the support ring (D).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER




Fig.3

Remove the lamp-bulb (I) if still present on the lamp device.




Fig.4

Remove the diffuser (H).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER




Fig.5

Remove the support ring (D) from the support brackets (E) by unfastening the screw/pivot.




Fig.6

Unfasten the three locking screws (A) of the lamp counterweight (B) present underneath the lamp base.  
Remove the counterweight (B) and unfasten the two clamps screws.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER



Fig.7

Unfasten the two screws (N) and lift up the lamp holder assembly (O) with his bracket.



Fig.8

Push down the brass hook (A).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER




Fig.9

Unfasten the sleeve (C) of the lamp holder.




Fig.10

Disconnect the electrical conductors (D) from the terminals of the lamp holder contacts.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER




Fig.11

Unfasten the screw of the cable clamp (E) and slide it off from the electrical cable.



Fig.12

Slide off the isolator (F) from the electrical cable.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER



Fig.13

Unfasten the internal screw (G) of the lamp holder support (H).




Fig.14

Remove the lamp holder support (H) from the bracket (I) by unfastening the nut (J) with a pair of adjustable pliers (K).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER



Fig.15

Assemble now the new spare-part:

Fasten the new lamp holder support (H) on the threaded pin (L).(Fig.15)

Fasten it well by fastening the nut (J) with the adjustable plier (K).(Fig.16)

Fasten the internal screw (G) present inside the lamp holder support (H). Slide through the electrical cable the isolator (F) and position it inside the lamp holder support (H).(Fig.12-13 page 28-29)

Insert the cable clamp (E) and fasten the locking screw.(Fig.11 page 28)

Connect the electrical wires (D) to the terminals of the lamp holder contacts respecting the polarities (L = Brown – N = Blue).(Fig.10 page 27)

Fasten the sleeve (C) on the lamp holder support and push the brass hook (A) back in a way that it hooks on to the sleeve (C). (Fig.8-9 page 25-26)

Assemble the lamp holder (O) with bracket, by fastening the two locking screws (N).(Fig.7 page 26)




Fig.16

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF04169

E27 LAMP HOLDER



Fig.17

Fasten the two screw (C) of the cable clamp and then assemble the lamp counterweight (B) by fastening the three locking screws (A).

Rest the support ring (D) on the support brackets (E) and lock it by fastening it with the screw/pivots. (Fig.5 page 25)

Insert the diffuser (H) and the lamp-bulb (I).(Fig.4 page 24)

Insert the lamp-bulb (I).(Fig.3 page 24)

Position the fabric lamp shade (N) on the support ring (D) ensuring to insert the hook threaded screws (R) into the apposite holes present in the support ring (D), fasten the small bolts (Q).

Collocate the silicone seats in there apposite holes underneath the cover ring (O). Rest the covering ring (O) on the pins (G).(Fig.1-2 page 23)




Fig.18

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF32262

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Bedside  
Gun  
p.12



Chiara T  
p.03



Glo-ball  
Basic 0  
p.11



Glo-ball  
Basic 1  
p.14



Glo-ball  
Basic 2  
p.05



Glo-ball  
T1  
p.11



Ic T1  
High  
p.08



Ic T1  
Low  
p.08



Ic T2  
p.08



Ktribe T1  
p.05



Ktribe T2  
p.05



Ray T  
p.17




Romeo  
Moon  
T1  
p.32



Romeo  
Soft T1  
p.32



Spun  
Light  
T1  
p.12



Spun  
Light  
T2  
p.12



Table  
Gun  
p.12

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF32262**

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Fig.1




Fig.2

Open the dimmer box of the damaged dimmer.  
For the opening, it is necessary to remove the n°2 screws using a star screw driver.

Lift-up the dimmer casing from the dimmer base;

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF32262

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W




Fig.3




Fig.3.1

Remove the cable clamps by unfastening the 4 screws (A) and disconnect the wires from the terminal blocks through a tiny flat headed screw driver;



Fig.4

Replace the dimmer and connect the wires. When connecting the wires it is necessary to respect the polarities (L = Brown and N = Blue) to the terminal box. Lock the electrical cables by fastening the screws (A) of the cable clamps and make sure to block the isolation of the electrical cable.

Close the dimmer box. It is necessary to place the casing on top and press down until it locks in. it is necessary to insert the n°2 screws using a star screw driver.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET



Romeo  
Moon T1  
p.35



Romeo  
Soft T1  
p.35

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET




Fig.1




Fig.2

Remove the cover ring (O).  
Remove the fabric lamp shade (N) by  
unfastening the small bolts (Q).  
Unhook the fabric shade from the support ring  
(D).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET




Fig.3

Remove the lamp-bulb (I) if still present on the lamp device.




Fig.4

Remove the diffuser (H).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET




Fig.5

Remove the support ring (D) from the support brackets (E) by unfastening the screw (F).




Fig.6

Unfasten the locking screw of the lamp counterweight present underneath the lamp base.  
Remove the counterweight (B) and unfasten the two clamp screw.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET



Fig.7

Unfasten the two screws (N) and lift up the lamp holder assembly (O) with his bracket.



Fig.8

Unfasten the two locking screws (P) and remove the damaged support bracket (E).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

## RF02813

T1 GREY SUPPORT BRACKET



Fig.9



Fig.10

Assemble now the new spare-part:

Collocate the new support bracket (E), ensuring that the holes (Q) present on the bracket correspond with the holes (R) present on the lamp cup (O).

Assemble the support bracket (E) by fastening the two screws (P).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

## RF02813

T1 GREY SUPPORT BRACKET




Fig.11

Assemble the lamp holder (O) with bracket, by fastening the two locking screws (N).



Fig.12

Fasten the two screws (C) of the cable clamp and then assemble the lamp counterweight by fastening the three locking screws. (Fig 6 page 38)

Rest the support ring (D) on the support brackets (S) and lock it by fastening it with the screws (F).

Insert the diffuser (H). (Fig. 4-5 page 37-38)

Insert the lamp-bulb. (Fig. 3 page 37)

Place the glass shade (P) on the support ring (D).

Rest the covering ring (M) on the internal glass diffuser (L). (Fig. 1 page 36)

ROMEO SOFT T1 F6107007

EN

## RF6138100

KIT OF TRANSPARENT PADS FOR LAMP BASE



Romeo  
Moon T1  
p.42



Romeo  
Soft T1  
p.42



Tatou T1  
p.18

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ROMEO SOFT T1 F6107007

EN

**RF6138100**

KIT OF TRANSPARENT PADS FOR LAMP BASE



Fig.1

Stick-on the feet (A) to the base.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.