


ITEM NO: M10067MBK
M10067NB



INSTALLATION INSTRUCTIONS

1. Carefully remove the fixture out of the carton, and check that all parts are included referring to the above illustration. Make sure not to misplace any parts that are needed for the installation;
2. Install the stem (8) into the arm (11).
3. Assemble the tube (7) together using the nipple (10), then attach the bottom end of tube (7) onto the coupling (9) tightly, then secure the swivel (6) onto the tube (7).
4. Install the fabric shade (2) into the socket (3).
5. Fixture is ready for lamping and installation.