


# STUDIO•M

**PRODUCT NAME:** Norma Jean Pendant  
**ITEM NUMBER:** SM23771BCSBR


Please consult your electrician for hanging fixture and wiring.




**Bulbs (Included):** 1 \* 2.3W G9 LED

MADE IN CHINA  
 Page 1 of (2)


**IMPORTANT:** Turn off the power at the main fuse or circuit breaker box before starting installation



Locate all hardware & components before discarding packaging




1.)




**Step 1:** Remove mounting bracket (A) and install to electrical box. Install mounting bracket and attach anchors to secure bracket at ends.

2.)




**Step 2:** Wire fixture to wires in outlet box. Black wire is positive, white wire is neutral, Green wire is for ground. Attach fixture to mounting bracket using screws (C).

3.)



**Step 3:** Adjust wire to desired hanging height. Install the G9 Bulb(E) provided.

4.)



**Step 4:** Thread the Crystal shade(F) into the socket(D).

**Cleaning & Care:**  
 Clean with soft cloth and a mild detergent.  
 Do not use abrasive cleaner.

Page 2 of (2)