


ASSEMBLY INSTRUCTIONS



Claremont 21" Open Ring Chandelier

Item # RL5108

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver	Slotted Screwdriver	Wire Strippers
Slip Joint Pliers	Measuring Tape	Chain Pliers
Wire Cutters		


1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Remove mounting plate **(B)** from canopy **(F)** by removing collar ring **(G)**.
3. Remove collar loop **(D)** from mounting plate **(B)** by unscrewing.
4. Install mounting plate **(B)** to the junction box and secure with mounting screws **(C)**.
5. Install driver **(J)** to mounting plate **(B)**, then secure collar loop **(D)** to mounting plate **(B)** using pliers to tighten locknut.
6. Install canopy **(F)** to collar loop **(D)** and secure with collar ring **(G)**.
7. Install rubber washers **(K)** and shade **(L)** to rods **(N)** and secure with threaded caps **(M)** (see diagram 1).
8. Determine desired overall length, and amount of chain **(H)** needed. Shorten chain using chain pliers. (Keep extra chain)
9. Attach chain **(H)** to collar loop **(D)** and to fixture loop **(I)** using "S" shaped quick links **(E)**.
10. Thread fixture wire and ground wire through chain **(H)**.

NOTE: When you reach the collar loop **(D)**, ensure there is no tension on the wires. Cut excess wires, being sure to leave enough to reach the junction box.

RALPH LAUREN



ASSEMBLY INSTRUCTIONS



Claremont 21" Open Ring Chandelier

Item # RL5108

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

11. Separate two sides of molded wire, and strip insulation on each 5/8".
12. Loosen collar ring **(G)** and let canopy **(F)** slip down chain **(H)** carefully.
13. Twist all fixture wires together, and slip through center hole of collar loop **(D)**.

NOTE: Untwist wires and separate to prepare for connection.

14. Wrap supply ground wire (usually green or bare copper) around the green grounding screw (see diagram 2). Tighten.

NOTE: It is imperative that the fixture is grounded.

15. Connect driver **(J)** input neutral wire (white) to the supply neutral wire (usually white) using wire nut **(A)**.
16. Connect driver **(J)** input hot wire (black) to the supply hot wire (usually black) using wire nut **(A)**.

CAUTION: Do not reverse the hot and neutral connection.

17. Connect fixture neutral wire (marked "-") to driver **(J)** output wire (black) using wire nut **(A)**.
18. Connect fixture hot wire (marked "+") to driver **(J)** output wire (red) using wire nut **(A)**.

CAUTION: Do not reverse the hot and neutral connections.

19. Make sure all wire connections are tight, then carefully tuck into the junction box.
20. Install canopy **(F)** to collar loop **(D)** and secure with collar ring **(G)**.

CARE INSTRUCTIONS: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

RALPH LAUREN

