



BLU  
DOT

MODULAR AND STYLISH,  
WHO KNEW?

# MODU- LICIOUS

## Queen / Full Bed

### ASSEMBLY INSTRUCTIONS




#### CARE










Clean with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for wood furniture. Wipe completely dry with a soft cloth in the direction of the wood grain.

Clean powder-coated units with a soft cloth or sponge using a mild detergent, such as dish soap, and warm water. Wipe completely dry with a soft cloth.

#### HARDWARE



#### PARTS LIST







# HOW TO USE CAM LOCK HARDWARE




1



2




3




Note direction of arrow on cam

4



Turn cam clockwise 1/2 turn

5



Note direction of arrow on cam

**1 ASSEMBLE ON CARPET OR PROTECTIVE MAT**

Part A will have 2 panels with drawer slides installed on the front side only (left) and 2 panels with drawer slides installed on the back side only (right).

Part B will have drawer slides installed on both the front and back sides.

Part A is thinner than Part B

First screw goes here

x24 1023

x2

x2

x4

**2**

x8 1611

x3 4010

x4

**3**

Repeat Steps 2 & 3 for opposite side drawer box assembly.

x8 5002

x4 5001

x4 5010

**4**

x4 4005

