



ASSEMBLY INSTRUCTIONS



BRYNNER TABLE LAMP

Thank for your purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.




HARDWARE LIST			
A		LAMP BASE	01
B		LAMP SHADE	01
C		HARP	01
D		FINIAL	01
E		BULB (NOT INCLUDED)	01

INSERT THE BULB AND HARP



**PLACE AND TIGHTEN
THE SHADE WITH
FINIAL AS ABOVE**



FINISHED

ASSEMBLY INSTRUCTIONS

BRYNNER TABLE LAMP

WIRING CONNECTIONS

No wiring is required, just insert the polarized plug in the outlet & turn on the power when lamp assembly is finished

IMPORTANT SAFETY INSTRUCTIONS

- 1 This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug outlet will fit in a polarized only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety features.
- 2 It is recommended to use 1 x150 - Watt maximum Type A bulb.
- 3 To avoid the risk of fire, do not exceed the recommended wattage.
- 4 The manufacturer and distributor accept no liability for incorrect installation.
- 5 For indoor use only

WARNINGS

When unpacking, be careful not to pull wire, as a bad connection may result. Do not connect electricity until your lamp is fully assembled. Do not touch or look directly at the bulb when lamp is illuminated.

TO ASSEMBLE

- 1 Stand lamp base on the flat surface
- 2 Remove the finial from the harp
- 3 Insert 01 Type A 150W 3 way bulb (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE
- 4 Place the harp in the Saddle.
- 5 Place the Shade onto the harp and tighten the Shade with finial
- 6 Insert the polarized plug in the outlet & turn on the power, to test the lamp

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.
Keep out of reach of children under 3 years of age.