


Assembly Instructions


IASR-109

BRINLEY TABLE LAMP


Step-1



Step-2



Step-3



Step-4

