




## Assembly of the sectionals



The prong and the connector must be aligned well.



## How to disconnect



Lift up the right sectional and pull it out

