







ASSEMBLY INSTRUCTION FOR NOELINE DOUBLE EXTENSION DINING TABLE

HARDWARE LIST


A		Bolt	M10 x 25mm	24
B		Washer	10 x 20mm	24
C		Lock Washer	10 mm	24
D		Allen Wrench	8 mm	1





COMPONENTS




1




2




3




4




5




6



7




8




9


MANUAL USER




10




11




12




13




14




15




16




17




18




19




20




21




22




23




24




25




26




27




28




29



30



31



32

