

Place the item in desired location, check if the item is level using a spirit level (not supplied). If not, have one person lift the item side that is not level, and another person turn this side's bottom adjustable glide a little bit (shown in the Figure A) until the bubble is in the center of the spirit level. Repeat adjustment as necessary until level.

