











ASSEMBLY INSTRUCTION FOR MODEL: EMMER COFFEE TABLE

HARDWARE LIST

A		Nut	Ø5/16" x 8mm	8
B		Lock Washer	Ø5/16"	8
C		Flat Washer	Ø5/16" x 19mm	8
D		Hexagonal Wrench	14mm	1



ASSEMBLY INSTRUCTION FOR MODEL: EMMER COFFEE TABLE



Adjustable Leveler

Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Adjust the Floor Levelers

Check for Stability - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers - These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.