






# ASSEMBLY INSTRUCTION

## MODEL: DINING TABLE


### HARDWARE LIST

A		Allen bolt	M8 x 47mm	8
B		Flat washer	Ø19 x Ø10 x 2mm	8
C		Allen wrench	M4	1



# ASSEMBLY INSTRUCTION

## MODEL: DINING TABLE



# INSTRUCTION FOR LEVELER

## MODEL: DINING TABLE

### ADJUSTING FLOOR LEVELERS

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

### ADJUST THE FLOOR LEVELERS

**Check for Stability** - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

**Locate the Levelers** - These are small adjustable feet found at the bottom corners of your furniture.

**Adjust as Needed** - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

