



ASSEMBLY INSTRUCTION




ASBURY MEDIA CONSOLE

STEP 1 : Lift the shelf from oneside.



STEP 2 : Turn anticlockwise to open shelf holders and tighten them at desired adjustment level.



STEP 3 : Repeat step 2 on the opposite wall and place the shelf at new adjustment.

