










# ASSEMBLY INSTRUCTION FOR

## MODEL: FLORENT EXTENSION DINING TABLE


Parts List				Name of Hardware			
1		Main top	1	A		Spanner	1
2		Leaf	1	B		Bolt M8x70mm	8
3		Leg	4	C		Flat Washer Ø19/Ø8x2mm	8
				D		Spring Washer Ø19/Ø8x2mm	8




Step 1




Step 2



Step 3



Step 4



## Adjust the Floor leveler:

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

**Check for Stability** - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

**Locate the Levelers** - These are small adjustable feet found at the bottom corners of your furniture.

**Adjust as Needed** - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

*If you need further adjustments, repeat the process in small increments.*

