






ASSEMBLY INSTRUCTION

CLEMENCE DINING CORNER PC





HARDWARE LIST

A		Leg	5Pcs
B		Lock Washers Ø40mm	5Pcs



ASSEMBLY INSTRUCTION



CLEMENCE DINING CORNER PC




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 127"


Assembly of the sectionals



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette U Shape 117.5"

Assembly of the sectionals




How to disconnect




ASSEMBLY INSTRUCTION

Clemence Dining Banquette U Shape 128"


Assembly of the sectionals



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 111.5"-Left


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 111.5"-Right


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 88.5"


Assembly of the sectionals



The prong and connector must be aligned well



How to disconnect



Lift up the right sectional and pull it out

