









# ASSEMBLY INSTRUCTION

## CLEMENCE RAF DINING BENCH 49"





### HARDWARE LIST

HARDWARE LIST			
A		Leg	4Pcs
B		Lock Washers Ø40mm	4Pcs



# ASSEMBLY INSTRUCTION


## CLEMENCE RAF DINING BENCH 49"




# ASSEMBLY INSTRUCTION

## Clemence Dining Banquette L Shape 127"


### Assembly of the sectionals




The prong and connector must be aligned well



### How to disconnect





Lift up the right sectional and pull it out




# ASSEMBLY INSTRUCTION

## Clemence Dining Banquette U Shape 117.5"


### Assembly of the sectionals



### How to disconnect





Lift up the right sectional and pull it out





# ASSEMBLY INSTRUCTION

## Clemence Dining Banquette U Shape 128"

### Assembly of the sectionals




### How to disconnect




# ASSEMBLY INSTRUCTION

## Clemence Dining Banquette L Shape 111.5"-Right


### Assembly of the sectionals




The prong and connector must be aligned well



### How to disconnect




Lift up the right sectional and pull it out




# ASSEMBLY INSTRUCTION

## Clemence Dining Banquette L Shape 88.5"


### Assembly of the sectionals



The prong and connector must be aligned well



### How to disconnect



Lift up the right sectional and pull it out

