







ASSEMBLY INSTRUCTION

CLEMENCE DINING CHAIR AND A HALF





HARDWARE LIST

A		Leg	4Pcs
B		Lock Washers Ø40mm	4Pcs



ASSEMBLY INSTRUCTION



CLEMENCE DINING CHAIR AND A HALF




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 127"


Assembly of the sectionals



How to disconnect




Lift up the right sectional and pull it out



ASSEMBLY INSTRUCTION

Clemence Dining Banquette U Shape 117.5"

Assembly of the sectionals



How to disconnect

