






ASSEMBLY INSTRUCTION

CLEMENCE DINING CORNER PC





HARDWARE LIST

A		Leg	5Pcs
B		Lock Washers Ø40mm	5Pcs



ASSEMBLY INSTRUCTION



CLEMENCE DINING CORNER PC




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 127"


Assembly of the sectionals



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette U Shape 117.5"

Assembly of the sectionals




How to disconnect



ASSEMBLY INSTRUCTION


Clemence Dining Banquette U Shape 128"

Assembly of the sectionals



The prong and connector must be aligned well

How to disconnect




Lift up the right sectional and pull it out


ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 111.5"-Left


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 111.5"-Right


Assembly of the sectionals




The prong and connector must be aligned well



How to disconnect




Lift up the right sectional and pull it out




ASSEMBLY INSTRUCTION

Clemence Dining Banquette L Shape 88.5"


Assembly of the sectionals



The prong and connector must be aligned well



How to disconnect



Lift up the right sectional and pull it out

