








Part List		ASSEMBLY INSTRUCTION	
1		ELLINGTON DINING BENCH 82"	
2		ELLINGTON DINING BENCH 72"	
3		ELLINGTON DINING BENCH 49"	
4		ELLINGTON DINING CHAIR AND A HALF	
5		ELLINGTON DINING CORNER PC	



*The prong and the connector must be aligned well.*



*For un-assemble the section, seperate the sections by lift from right to left.*

