






Part List		ASSEMBLY INSTRUCTION	
		254502 - Ellington Dining Banquette U Shape 105"	
1		Ellington Dining Bench 49"	
2		Ellington Dining Chair And A Half	
3		Ellington Dining Corner PC	



*The prong and the connector must be aligned well.*



*For un-assemble the section, seperate the sections by lift from right to left.*

