










ASSEMBLY INSTRUCTION

MODEL: WOODEN COFFEE TABLE MARBLE TOP

HARDWARE LIST


A		Steel Hexagonal bolt	Ø10 x 75mm	4
B		Flat washer	Ø19 x Ø10 x 2mm	4
C		Socket wrench	M17	1
D		Steel allen bolt	Ø8 x 47mm	4
E		Lock washer	Ø12 x Ø10 x 3mm	4
F		Flat washer	Ø19 x Ø10 x 2mm	4
G		Steel allen wrench	M4	1




ASSEMBLY INSTRUCTION

MODEL: WOODEN COFFEE TABLE MARBLE TOP

STEP 1:



STEP 2:



INSTRUCTION FOR LEVELER

MODEL: WOODEN COFFEE TABLE MARBLE TOP

ADJUSTING FLOOR LEVELERS

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

ADJUST THE FLOOR LEVELERS

Check for Stability - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers - These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

