











ASSEMBLY INSTRUCTION FOR

Chamberlain Dining Table


No.	Hardware/Component List		Quantity	No.	Hardware/Component List		Quantity
1		Top	01	5		Alen Bolt 8x25mm	04
2		Legs	02	6		Alen Bolt 8x35mm	02
3		Stretcher	01	7		Alen Bolt 8x50mm	08
4		Stretcher	01	8		Alen Key 5mm	01




Step 1



Step 2



Step 3



Step 4

Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the drawers are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Check for Stability – Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers – These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed – Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

