



# ASSEMBLY INSTRUCTION

## Langham Sectional


### Universal assembly of the sectionals



The prong and the connector must be aligned well.



### How to disconnect



Lift up the right sectional and pull it out .

