


ASSEMBLY INSTRUCTION

Langham Channeled RAF PC

Universal assembly of the sectionals



The prong and the connector must be aligned well.



How to disconnect



Lift up the left sectional and pull it out.

