


ASSEMBLY INSTRUCTION


Dorset RAF 49.5" Dining Bench



ASSEMBLY INSTRUCTION

Dorset Banquette U Shape 102.5"



Assembly of the sectionals.



- Align the connectors, lift one sectional slightly, then lower it to lock them together.
- Follow Steps 1–4 in order.

How to disconnect.


Lift the sectional slightly and pull it apart.



ASSEMBLY INSTRUCTION



Dorset Banquette U Shape 130"

Assembly of the sectionals.



How to disconnect.


Lift the sectional slightly and pull it apart.



ASSEMBLY INSTRUCTION


Dorset Banquette L Shape 76"

Assembly of the sectionals.




- Align the connectors, lift one sectional slightly, then lower it to lock them together.
- Follow Steps 1–2 in order.

How to disconnect.





Lift the sectional slightly and pull it apart.



ASSEMBLY INSTRUCTION



Dorset Banquette L Shape 114.5"

Assembly of the sectionals.



- Align the connectors, lift one sectional slightly, then lower it to lock them together.
- Follow Steps 1–3 in order.

How to disconnect.




Lift the sectional slightly and pull it apart.


ASSEMBLY INSTRUCTION

Dorset Banquette L Shape 98.5" - Right


Assembly of the sectionals.



- Align the connectors, lift one sectional slightly, then lower it to lock them together.
- Follow Steps 1–2 in order.



How to disconnect.



Lift the sectional slightly and pull it apart.

