


ASSEMBLY INSTRUCTION
MODEL: CLEMENS MEDIA CONSOLE

HARDWARE LIST				
A		Shelf Holder	Ø7 x 10 x 20mm	8







INSTRUCTION FOR LEVELER
MODEL: CLEMENS MEDIA CONSOLE

ADJUSTING FLOOR LEVELERS


Your furniture has been expertly crafted and pre-adjusted by professionals. However. slight shifts can occur during transportation, If you notice that the doors are not perfecty aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

ADJUST THE FLOOR LEVELERS

Check for Stability - Place the fumiture in its final position on a level surface, If it wobbles or doesnit sit evenly, the floor levelers need adjusung.

Locate the Levelers - These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed - Using your hand or a wrench, tum the levelers clockwise to raise or counterclockwise to lower the furniture. Make smal adjustments and check stabiity atter each turn.



INSTRUCTION FOR DOOR HINGE

Adjust the Hinges (If Necessary)

Once the furniture is level, check the doors. If they appear misaligned or don't close properly:


Make sure that the furniture is level left to right and front to back before attempting to adjust the hinges

Identify the Hinges - The hinges have adjustment screws that control movement in different directions.

1. Up and Down Adjustment: To move the cabinet door higher or lower.

2.Left and Right Adjustment: To shift the cabinet door sideways for alignment.

3.Back and Forth Adjustment: To move the cabinet door closer to or farther from the cabinet frame.



TIPS FOR ADJUSTMENT:

These "adjustments" are not preset and will need to be checked to meet the desired look.

- We recommend the use of a **#2 Phillips Screwdriver**.
- Adjust **in small steps** and check your progress frequently.
- Use a **measuring tape** to ensure the gaps between the top and bottom of the door are even.
- Avoid forcing the door closed if it does not align properly, as this may damage the door.
- If the alignment is still off, make further adjustments as needed.

By following these steps, you can achieve a balanced door alignment.