
ASSEMBLY INSTRUCTIONS

ARTERIORS

ITEM DESCRIPTION:

ITEM NO.: PAI04	**NAME:** Vulcain Accent Lamp
MATERIAL TYPE: Aluminum	**FINISH:** Antique Brass
SOCKET TYPE: E26 / Type A	**SOCKET QTY:** 1
BULB WATTAGE: 150W	**VOLTAGE:** 250V
ITEM NET WEIGHT: 7.49 LBS	**Qty:** 1





PARTS INCLUDED:

FINIAL (A)	1	HARP TOP (B)	1
HARP (C)	1	HARP CAPS (D)	2
SADDLE (F)	1	SHADE (G)	1

PRE-ASSEMBLY:

· Remove all parts and hardware from the box, along with any protective plastic packaging. · Do not discard any packaging until assembly is complete, to avoid throwing away small parts or hardware.

TO ASSEMBLE:

1. PLACE THE LAMP ON A FLAT, STABLE SURFACE.
2. INSERT THE ENDS OF THE HARP (C) INTO THE SADDLE (F) AND SLIDE THE TWO HARP CAPS (D) DOWN TO LOCK THE HARP IN PLACE.
3. INSERT A BULB (NOT INCLUDED) INTO THE SOCKET (E). DO NOT EXCEED THE MAXIMUM WATTAGE.
4. UNSCREW THE FINIAL (A) FROM THE HARP TOP (B). PLACE THE SHADE (G) OVER THE HARP SO THE HARP TOP PASSES THROUGH THE SHADE FITTER.
5. SCREW THE FINIAL (A) BACK ONTO THE HARP TOP (B) AND TIGHTEN TO SECURE THE SHADE.

IMPORTANT SAFETY INSTRUCTIONS:

This lamp has a polarized plug (one blade is wider than the other) for North American outlets. It fits a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse it; if it still does not fit, contact a qualified electrician. Use with an extension cord only if the plug can be fully inserted. Never alter the plug. Read these instructions carefully and completely before assembling the lamp. To avoid the risk of fire, do not exceed the maximum bulb wattage.

WARNING:

· To reduce the risk of fire, electric shock or personal injury, always turn off and unplug the lamp and let it cool before replacing the bulb.

· Do not touch the bulb while the lamp is on. Do not look directly at a lit bulb.

· Keep flammable materials away from a lit bulb.

CARE INSTRUCTIONS:

· Clean with a soft, dry cloth. · Avoid harsh chemicals or abrasive cleaners, which may damage the finish.