



Our teak is sustainably sourced Grade A solid wood. Teak's natural characteristics make it highly suitable for outdoor use. Keep in mind, graining and color may differ between pieces due to natural variations in the wood. Teak also weathers to a silver-gray patina over time. How much and how quickly it changes depends on climate, exposure to elements and level of care. Temperature changes cause teak to naturally expand and contract, sometimes resulting in hairline cracks. These should not affect the structural integrity of the design.

Caring for Teak

Teak's natural oils make it ideal for outdoors—preventing rot and making it resistant to fungus and wood-boring insects. Avoid letting water stand on surfaces. This can cause teak's natural oils to surface and appear as water stains. Over time, exposure to moisture can also raise the wood grain. Simply sand with fine sandpaper to smooth it out.

To prevent excess fading and weathering, we recommend covering your product when not in use. If you prefer your teak less silvergray, we suggest using Bayes Teak Cleaner and Restorer to help maintain its original color or bring some of it back if already weathered. Apply according to manufacturers' instructions for best results.

To remove dirt, pollen or mildew from the teak surface, a solution of equal parts water and white vinegar or bleach can be applied to the area. Stronger stains might require a commercial teak cleaner as listed above.



Natural Teak | **New**



Natural Teak | **After 1 Year**