



Hold Tight Outdoor Dining Table

DESIGNED IN 2023

ASSEMBLY NOTES | REV 00




NEED A HAND?

Contact us at service@bludot.com or
844.425.8368 for assistance.

@BLUDOT


We design all our pieces in our Minneapolis studio. Follow
along on Instagram for some sneak peeks into the process.

Parts & Hardware




QTY 8

PT. 1603



QTY 8

PT. 1705



QTY 16

PT. 3002




QTY 1

PT. 9016



QTY 2

Leg



QTY 1


Table Top

Step 01


ATTACH LEGS.

Assemble this product on a soft clean surface. Insert the legs into the table top and attach them using the hardware provided as shown. Install the longer **PT.1705** bolts before shorter **PT. 1603** bolts. Ensure that the correct length hardware is used in each location.


Do not fully tighten bolts until all connection locations have been attached. Carefully lift the table upright with the help of another individual to complete installation.




PT. 1603 x 8



PT. 1705 x 8



PT. 3002 x 16



PT. 9016 x 1

Additional Information

CLEAN METAL

Clean metal surfaces with a slightly damp, soft cloth. To remove dirt and fingerprints, use a quality cleaner formulated for metal furniture. Wipe completely dry with a soft cloth.

TEAK NOTES

Our teak is sustainably sourced Grade A solid wood. Teak's natural characteristics make it highly suitable for outdoor use. Keep in mind, graining and color may differ between pieces due to natural variations in the wood. Teak also weathers to a silver-gray patina over time. How much and how quickly it changes depends on climate, exposure to elements and level of care. Temperature changes cause teak to naturally expand and contract, sometimes resulting in hairline cracks. These should not affect the structural integrity of the design.

TEAK CARE

Teak's natural oils make it ideal for outdoors—preventing rot and making it resistant to fungus and wood-boring insects. Avoid letting water stand on surfaces. This can cause teak's natural oils to surface and appear as water stains. Over time, exposure to moisture can also raise the wood grain. Simply sand with fine sandpaper to smooth it out.

To keep your teak looking extra pretty, we recommend covering it when not in use. If you prefer your teak less silver-gray, we suggest using Bayes Teak Cleaner and Restorer to help maintain its original color or bring some of it back if already weathered. Apply according to manufacturers' instructions for best results.