

SAFETY INSTRUCTIONS

The consumer is responsible for reading and understanding all safety information BEFORE using this device. Failure to do so may result in injury, electrical shock, or fire.

• This product contains a rechargeable Lithium-ion battery. Fire and explosion hazards exist when batteries are damaged or are used improperly.

• To reduce risk of electric shock, use charging cable in an indoor dry location only. Do not charge near water / liquid. Do not place, store or charge lamp where it can fall into water. Do not submerge the product in water. The charging cable is intended for indoor use only. Do not use charging cable outdoors.

• Only use the charging cable provided with this device.

• Practice care to ensure doors/windows/drawers are not closed on the charging cable. Crimping or fraying of the charging cable may result.

-IMPORTANT- Periodically inspect the charging cable for cuts or other damage. Discontinue use of charging cable if defects are observed.

• Do not use this product if the housing, battery, or LED source are damaged.

• If this product becomes damaged, dispose of properly in accordance with federal and local laws/directives for disposal of lithium ion batteries.

• To minimize risk of fire, charge and operate this device in open air only. Do not cover this device with any material. Do not operate or store this product near combustible materials.

• Do not place or dispose of this product in a fire. A dangerous explosion may occur.

• Do not crush this product or the associated battery. A dangerous explosion may occur.

• Recommended operating temperature for this product is 14°F to 122°F (-10°C to 50°C).

• Recommended charging temperature for this product is 32°F to 113°F (0°C to 45°C).

• Do not expose this product to temperatures exceeding 140°F (60°C) or humidity exceeding 95%.

• To reduce risk of injury, provide close adult supervision if appliance is operated by children.

• This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Save these instructions for future reference.

CARE AND CLEANING

Ensure device is unplugged and turned off during cleaning.

Do not use:

Chemical cleaning agents
Solvents
Harsh abrasives.

Use a non-abrasive dry or slightly damp cloth to lightly clean or dust the product surfaces.

Periodically inspect lamp and charging cord for degradation due to weather, UV light, or other factors. If damage is noted to the lamp, charging cable, or charging block (not included), do not operate or charge the lamp.

Limited Warranty:

1 year from the date of purchase. If product fails within the warranty period, contact:

Bulbrite Industries, Inc.
returns@bulbrite.com

Bulbrite standard warranty terms and conditions shall apply.
bulbrite.com/kibun

©2025

Made with love from your friends at Kibün by Bulbrite.

Designed and Engineered in U.S.A.

Manufactured in China. All rights reserved.




Show off your style!

Show off your space with your new cordless lamp! Tag us @Bulbrite and use #kibunliving—we'd love to see it!

CARE AND USE GUIDE

 **kibün**
by Bulbrite



**Rechargeable
USB Battery**

**Groove
LED Cordless Table Lamp**

ITEM #
K80160