








# ASSEMBLY INSTRUCTIONS

SKU# 51012051

## PARTS LIST

A	WOODEN TOP x1		<p>Before Beginning</p> <p>1 - Carefully unpack and position the item on a clean, non-marring surface to assemble.</p> <p>2 - Read this Assembly Instructions from beginning to end before starting to assemble.</p> <p>3 - Take an inventory of the required parts to ensure all are available.</p> <p>4 - To prevent accidental choking hazards, keep all packing materials away from small children.</p> <p>5 - Only tighten hardware until ALL hardware are fully engaged on their locations. Overtighten bolts will damage the bolt threads.</p> <p>6 - Use only factory provided hardware to assemble. Unapproved hardware can damage product or jeopardize the structural integrity of the product.</p> <p>7 - The use of power tool to assemble is not recommended due to high risk of over-torque, which can damage the product.</p>		
B	CARCASS x1				
C	SIDE LEG x1				
D	ASSEMBLY PLATES x6				
Z	HARDWARE	<p>Z1</p>  <p>M8 x 20MM x 18</p>	<p>Z2</p>  <p>5 MM x 1</p>		



TWO PEOPLE



15-MINUTE  
ASSEMBLY TIME




KEEP INSTRUCTIONS  
FOR FUTURE USE




# ASSEMBLY INSTRUCTIONS

SKU# 51012051

1



2



3

