

Care Instructions

Overhang Laptop table – designed by Terence Woodgate

To prolong the life of the product and retain its appearance and functionality, we would like to give you some relevant information and care advice:

This unit is manufactured with either oak or walnut and with a laminate top.

Craftsmen manufacture this product and there is variety between each unit. This is because wood is a natural product, with natural colour and grain variations.



Natural timber is affected by sunlight; this can cause the wood colour to darken. For this reason (especially if placed in direct sunlight) it is recommended that placing objects in the same position for long periods of time is avoided. This potential colour adjustment becomes less relevant as the product ages.

It is recommended that no abrasive cleaners or solvents are used to clean the unit. Please only use proprietary furniture polishes or alternatively, warm water with a diluted mild detergent.

We thank you for purchasing this product and wish you many years of enjoyable and functional use.


For more related products please visit: casefurniture.com

Overhang Laptop table



Assembly Instructions

The instructions are the same for the Rectangular laptop table.



1 To allow access to the fixing holes on the underside of the base. Assemble the top with the central column and base upside down.

2 Assemble A and C together, making sure to fully tighten. Thread A and C assembly through holes in base, full tighten into top using B.

