


Assembly Instruction Sheet #S-1121P28
For Style 1121P28

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.
Light Source: (14) LED G9 MAX 5W (Not Included)
Estimated Assembly Time: 18-30 minutes
Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams prior to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

A. Warnings and Cautions
Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Package Contents



A Fixture Body x1

B Glass x7

C Glass x7

STEP 1 - Release Crossbar from Ceiling Canopy .




Figure 1

Hardware Contents

PART	DESCRIPTION	QUANTITY
BB	wire nut	2pcs
CC	Screw	2pcs




Figure 2

STEP 2 - Attach Crossbar to Outlet Box

STEP 3 - Wire Connections

A. Use standard wire connections to make all wire connections. Twist connections until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully seal all the connected wires into the Outlet Box.




Figure 3

STEP 4 - Install Ceiling Canopy to Ceiling




Figure 4

STEP 5 - Install Glass and bulb.




Figure 5

Figure 6

