

INSTALLATION INSTRUCTIONS

LED Pendant

PD-97552

dweLED

CAUTION: To prevent electrical shock, ensure electricity has been turned off at the circuit breaker before beginning.

- Read all instructions before installing.
- System is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.
- Retain installation instructions for future maintenance reference.

WARNING: All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by dweLED. Substitution of parts or accessories not designated for use with this product by dweLED could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

MAINTENANCE NOTE: Coastal conditions may cause mineral and residue build-up on the fixture. We recommend that customers in coastal areas clean all external surfaces of the fixture once every two weeks with a wet cloth.

MISE EN GARDE: Pour éviter tout choc électrique, assurez-vous que le disjoncteur soit mis hors tension avant de commencer.

- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licencié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.

ATTENTION: Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits dweLED. Remplacer des pièces ou accessoires non conçus pour ce produit dweLED pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

NOTE D'ENTRETIEN: Les conditions côtières peut causer une accumulation de minéraux et de résidus sur le luminaire. Nous recommandons aux clients qui résident dans les zones côtières de nettoyer toutes les surfaces externes du luminaire une fois toutes les deux semaines avec un chiffon humide.

HARDWARE

A



Wire Connector
Qty: 3pcs+1 Extra

B



Mounting Screw
Qty: 1 Extra

C



Plastic Anchor
Qty: 2pcs+1 Extra

D



Anchor Screw
Qty: 2pcs+1 Extra

E



Set Screws
Qty: 1 Extra

wacighting.com
Phone (800) 526.2588
Fax (800) 526.2585


Headquarters, East Manufacturing Facility
44 Harbor Park Drive
Port Washington, NY 11050

South East Manufacturing Facility
1600 Distribution Ct
Lithia Springs, GA 30122

Central Manufacturing Facility
1700 South J Elmer Freeway, Ste 100
Cedar Hill, TX 75104

West Manufacturing Facility
1750 S Archibald Ave
Ontario, CA 91761

Fig. 1



Mounting Plate Dimensions




Fig. 2 Wiring

Fig. 5 Belt adjustment





Fig. 3 4CCT switch



PREPARATION

1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts in a clear area. Be careful not to lose any small parts necessary for installation.

MOUNTING THE FIXTURE (Fig. 1 Fig.3 Fig.4)

3. Remove the mounting screw (B) from the fixture.
4. The lamp can switch between four color temperatures (2700K-3000K-3500K-4000K), which can be adjusted to your preference with the switch in the canopy (Fig.3). Set to desired color temperature.

Note: (i) The switch comes with a detachable switch cover, remove the switch cover prior to adjusting the color temperature, reattach the switch cover after adjustment is made.

(ii) Fixture must be powered off to adjust the CCT setting, after each CCT adjustment cycle power on, off then on to show new CCT setting.

(iii) There are a total of two switches, and the color temperature needs to be adjusted by turning the switches simultaneously.

5. Drill holes in the ceiling aligned with the key holes located on the ceiling plate, insert the plastic anchor (C).
6. Secure ceiling plate to the junction box using standard junction box screws that comes with the junction box, fasten it to the wall using anchor screw (D).
 - (i) It is recommended to use only original junction box screws or replacements provided by junction box manufacturer.
 - (ii) The side of the mounting plate marked "GND" must face out.
7. Remove the fixed plate and set screw (E). separate the belt and fixture.
8. Determine the length of the cut belt according to individual needs. Cut along the dotted line, do not cut the wire at this stage.
9. Put the belt back on the fixture than secure it tightly with fixed plate and set screw (E).

CONNECTING THE WIRES (Fig. 2)

10. Attach the fixture to the bracket on the mounting plate using a support cord as shown (Fig. 1). This secures the fixture and aids in wiring.
11. Connect the driver's input wires to the junction box wires as shown in Fig. 2 using wire connectors (A) provided. Ensure wire connectors are secure. Connect the fixture's ground wire to the ground in the junction box; this will be either a green wire or a bare copper wire. After fixture is wired to house wires, tuck wires carefully inside the junction box.


COMPLETING THE INSTALLATION

12. Mount the canopy against the mounting plate. Secure the fixture using the mounting screws (B).

DIMMING WIRING INFORMATION

13. This fixture features electronic low voltage (ELV or TRIAC) or 0-10V dimming capabilities. See notes below for specific dimming wires information.
 14. To utilize ELV or TRIAC dimming: use wires black (hot), white (neutral) and bare copper ground wire (ground).
 15. To utilize 0-10V dimming: use wire purple (dim+), gray or pink (dim-), black (hot), white (neutral) and bare copper ground wire (ground).
- Note:** Make sure to connect 0-10V prior to power-up the fixture in order to allow the 0-10V dimmer to function properly.

Fig.4 Wire Diagram



本页仅用于版本控制，请勿印刷！

THIS PAGE IS FOR VERSION CONTROL ONLY, PLEASE DO NOT PRINT !

| 序号 REV NO. | 变更说明 REVISION NTOE | 变更人 CHANGED BY | 变更日期 REV DATE |
|---------------|--------------------------------------|-------------------|------------------|
| 1 | 增加两个开关描述/Add two switch descriptions | 罗军 | 2025/09/08 |
| | | | |
| | | | |
| | | | |

料号：7DDB001360
PART NO.

设计：罗军 01/23/2025
DESIGNED BY

规格：80 克进口书写纸 A4，双面印刷，短边对折，中间装订
Specifications: 80g imported writing paper A4, double-sided printing, long side folded twice

审核：
CHECKED BY

标准化：
STD BY

图号：PD97552-20 B
DRAWING NO.

批准：
APPROVED BY