

INSTALLATION INSTRUCTIONS

LED Pendant

PD-48516/PD-48520

dweLED

CAUTION: To prevent electrical shock, ensure electricity has been turned off at the circuit breaker before beginning.

- Read all instructions before installing.
- System is intended for installation by a licensed electrician in accordance with the National Electrical Code (NEC) and local regulations.
- When handling the fixture, do not apply pressure to the LEDs. Hold the fixture by the base only.
- Retain installation instructions for future maintenance reference.

WARNING: All parts must be used as indicated in these instructions. This product is designed for use only with the supplied parts and/or accessories designated for use by dweLED. Substitution of parts or accessories not designated for use with this product by dweLED could result in personal injury or property damage, and will void the warranty. Contact an authorized dealer or the manufacturer if any parts are damaged or missing.

MAINTENANCE NOTE: Coastal conditions may cause mineral and residue build-up on the fixture. We recommend that customers in coastal areas clean all external surfaces of the fixture once every two weeks with a wet cloth.

MISE EN GARDE: Pour éviter tout choc électrique, assurez-vous que le disjoncteur soit mis hors tension avant de commencer.


- Lisez toutes les instructions avant l'installation.
- Le système doit être installé par un électricien licencié conformément au code national de l'électricité (NEC), et également aux règlements locaux.
- Lors de la manipulation du luminaire, n'appuyez pas sur les LED. Tenez-le uniquement par la base.

ATTENTION: Toutes les pièces doivent être utilisées comme indiqué dans ces instructions. Ce produit est conçu pour être utilisé seulement avec les pièces et/ou accessoires fournis pour être utilisés avec les produits dweLED. Remplacer des pièces ou accessoires non conçus pour ce produit dweLED pourrait causer des dommages corporels ou matériels et pourrait également causer l'annulation de la garantie. Veuillez contacter un revendeur autorisé ou le fabricant si des pièces manquent ou sont endommagées.

NOTE D'ENTRETIEN: Les conditions côtières peut causer une accumulation de minéraux et de résidus sur le luminaire. Nous recommandons aux clients qui résident dans les zones côtières de nettoyer toutes les surfaces externes du luminaire une fois toutes les deux semaines avec un chiffon humide.

Hardware

A



Wire Connector
Qty: 3PCS+1 Extra

B




Canopy Screw
Qty: 1 Extra

C



Allen Screw
Qty: 1 Extra

D



Allen Wrench
Qty: 1 pc

Wac Lighting.com

Phone (800) 526.2588

Fax (800) 526.2585

Headquarters/Eastern Distribution Center

44 Harbor Park Drive

Port Washington, NY 11050

Central Distribution Center

1600 Distribution Ct

Lithia Springs, GA 30122

Western Distribution Center

1750 Archibald Avenue

Ontario, CA 91760



INSTALLATION INSTRUCTIONS

LED Pendant

PD-48516/PD-48520

dweLED

PREPARATION

1. Shut off the power at the circuit breaker and remove existing fixture, including the crossbar.
2. Carefully unpack your new fixture and lay out all the parts on a clear area. Be careful not to lose any small parts necessary for installation.

MOUNTING THE FIXTURE (Fig. 1)

3. Remove the Canopy screw (B) from the ceiling plate.
4. Unscrew the three nuts, place the inner cover through the outer glass.

Note: (i) The end of the outer glass with a decorative ring faces down;

(ii) The inner cover needs to be tilted to fit into the upper end of the outer glass.

5. Use allen wrench (D) to loosen the allen screw (C) on the inner cover, screw the inner glass into the inner cover, and then tighten the allen screw (not too tight, otherwise it may cause the inner glass to break).
6. Use the cable to lift the inner cover until it protrudes from the outer glass, place the outer cover over the inner cover, and screw the three nuts tight.

7. Adjust the fixture wire length by pushing the cable gripper on the canopy and pulling the wire as desired. Retract these wires close to a desirable length to with the canopy before securing the fixture in place. Using the cable gripper to adjust more than 120" of wire length is not desirable

Warning: (i) Shortening these cables without professional helps or electronic background is not advisable.

(ii) Any modifications to the fixture will result in voiding the warranty of the product.

8. The lamp can switch between four color temperatures (2700K-3000K-3500K-4000K),

Note: (i) The switch comes with removable protective cover, Remove the cover prior to making adjustment, Reinstall the cover after adjustment is made.


(ii) Fixture must be powered off to adjust the CCT setting, after each CCT adjustment cycle power on, off then on to show new CCT setting.

9. Secure the ceiling plate to the junction box using the screws provided with the junction box.

Note: (i) Using any other non-original-manufacturer provided junction box screw may result in safety issue;

(ii) The side of the mounting plate marked "GND" must face out.

FIG. 1



CONNECTING THE WIRES (Fig. 3, Fig. 4)

10. Connect the driver input wires to junction box as shown in Fig. 3. Making sure that all wire connectors (A) are secured. If your outlet box has a green or bare copper ground wire, connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the back plate using the GND screw provided. After wires are connected, tuck them carefully inside the junction box.


COMPLETING THE INSTALLATION (Fig. 1)

11. Secure the canopy to the ceiling plate use the canopy screw (B).
12. After the fixture is installed, the inner glass may not be in the center of the outerglass, at this point, you can loosen three nuts slightly and adjust the outer cover to the desired position.

FIG. 3 Wiring

	Fixture Wires	House Wires
	Black or Smooth	Black (Hot)
	White or Ribbed	White (Neutral)
	Fixture Wires	House Wires
	Bare wire (Ground)	Green or Bare Copper (Ground)

Fig.4 Driver Wires



Ceiling Plate Dimensions

